

PIR Wireless Sensor

INCLUDE


- PIR Wireless Sensor x 1pc
- Bracket x 1pc
- Screws x 2pcs

FEATURE

- Technology with PIR (Pyro-electric Passive Infra-Red) motion sensor
- PIR Wireless Sensor detects temperature changes in infra-red radiation within the PIR coverage area
- Once PIR Wireless Sensor detects a temperature change, it will be triggered (red LED ON) and send a signal to the main unit that someone or something is approaching
- Up to 60 degree Horizontal & 6 degree Vertical sensor angle up to 5 meter detected distance

OPEATION

1. Slide the bracket to the PIR Wireless Sensor (see Drawing)
2. Follow the polarity instruction to install 3pcs of AA batteries, Alkaline is recommended (not included)
3. Make sure the PIR Wireless Sensor has successfully learned code with Main Unit instruction



4. Mount the PIR Wireless Sensor to proper location you want to monitor, such as, entrance, garage, stair, balcony, gate...etc.
5. When people walk by, PIR Wireless Sensor will be triggered (red LED ON) and the Main Unit will be alarmed

NOTE

1. If battery power is weak, the PIR red LED will flash every 3 minutes to remind the user to replace new battery
2. For best performance and distance, please keep the PIR Wireless Sensor away from the metal objects
3. The PIR coverage and distance might be various from different environment
4. The PIR sensor has a 3 seconds interval between each triggering
5. This product is designed for indoor use, so please keep away from water, direct sun light or microwave
6. Mount your PIR Wireless Sensor higher to avoid miss-trigger by pets
7. This product is detecting temperature, so please keep away from heat to avoid miss-triggering