


DX-125

MINI PERSONAL ALARM



SECURITY

An incredibly small size alarm with high-pitched 105 dB resonating alarm sound.

DX-125

MINI PERSONAL ALARM

FEATURE

- Incredibly small in size
- Simple emergency ripcord activation
- High pitch alarm sound
- Easy to carry and comfortable to hold

HOW TO REPLACE (INSTALL) BATTERY?

- Make sure the ripcord is inserted completely inside of the alarm before replacing (installing) battery.
- Unscrew the back cover
- Follow the polarity instruction (see drawing) to Insert 1pc of fresh CR2025 (included)
- Replace the cover gently

HOW TO OPERATE?


Pull the ripcord for an emergency to scare the assailant.

NOTE:

Always clip the SUPER MINI ALARM on the strap of your apparel or purse. Do not put it inside of your pocket or purse.

WARNING:

- The piercing high pitch alarm sound might injure the hearing if it's too close to the ears.
- This alarm contains small parts, and it is not suitable for small children.



Pat. Pending
Made in China




THIS PAPER BOARD
IS RECYCLABLE



4 717432 001913

80 mm




180 mm



105 mm

25 mm



17 mm

25 mm